



540 S. St. Clair St. Toledo OH 43604
419-720-8800
Greatlakesparty.com

Nacho Cheese Machine Instructions

Step 1

Place the machine on a secure level table top and plug the unit into a 120 Volt, 15 Amp outlet. The machine turns on automatically when plugged in.

Step 2

Peel off ring tab seal on product bag. Puncture tube through the seal and screw tube into place.

Step 3

Open the front door of the warmer. Open the tube clamp by turning the cam counterclockwise.

Step 4

Place the product on the rack with the spout and tube directed toward the front, and downward through the opening. Guide the tube through the pump slot from top to bottom. Close the tube clamp by turning the cam clockwise, and close the warmer front door. Let cheese heat up

Step 5

Once the cheese has run out, open the front door of the warmer, open the tube clamp, and remove the tubing by pulling from the bottom up. Remove the product bag and tube from the cheese dispenser. If desired replace cheese and tube, and start again. If finished using the machine follow cleaning instructions below.

Cleaning

After you're finished using the machine remove bag from machine. Wipe off any existing cheese from machine.

Parts

Be sure to return all the supplied parts:
Nacho Cheese Machine

Tips

Caution: Parts of the machine will be hot.

Dispensing temperature for cheese is between 140°F and 155°F

For large parties put a 2nd bag in machine to preheat.

Make sure the dispensing tube is sticking out at least a ½" out of the machine.