



540 S. St. Clair St. Toledo OH 43604
419-720-8800
Greatlakesparty.com

Snow Cone Machine Instructions

Step 1

Place unit on a secure table top and plug unit into electricity outlet.

Step 2

Fill the hopper within an inch from the top with ice cubes.

Step 3

Press and hold motor button to activate the cutting head. Wait for the unit to come up to speed. Push the pusher handle down against the ice in the hopper. Apply firm and even pressure to make the best snow. This allows the ice to resettle against the shaver head.

Step 4

Snow will collect in the bottom compartment. Use the scoop to fill cone(s) with shaved ice. Apply any flavored syrups as desired.

Cleaning

Remove all ice from the ice horn and storage compartment.

Operate the motor for several minutes to remove any water collection on the cutter head.

Unplug the power cord from the electrical outlet.

Using a clean cloth, wipe down unit.

Parts

Be sure to return all the supplied parts

Snow Cone Machine

Spoon

Hose.

Tips

Do not force the handle or the Motor will stall

When too much pressure is necessary, relieve the handle, and come down again. Too much pressure on the pusher handle will make the ice come out coarse; too little pressure makes the ice mushy.